

IMPORTANT FDP SPORT WIRING INFORMATION

Please note the two patch harness options:

- 1.** For 4 Channel input using the RCA Harness or the Harley Harness **WITH FACTORY REAR SPEAKERS**, you will need to use **BOTH** patch harness "A" and patch harness "B".
- 2.** For 2 Channel input using the RCA Harness (Ch 1 & 2 inputs), or the Harley Harness **WITHOUT FACTORY REAR SPEAKERS**, you will need to use **ONLY** patch harness "A".






FOCAL
LISTEN BEYOND

VISIT US ONLINE:

WWW.FOCAL-AMERICA.COM

The outputs use the standard color code as follows:

CH 1	Front Left	White ⊕	and	White / Black ⊖
				
CH 2	Front Right	Grey ⊕	and	Grey / Black ⊖
				
CH 3	Rear Left	Green ⊕	and	Green / Black ⊖
				
CH 4	Rear Right	Purple ⊕	and	Purple / Black ⊖
		