

IMPORTANT FDP SPORT WIRING INFORMATION

FOR 2 CHANNEL INPUT USING THE RCA HARNESS (CH 1&2 INPUTS)
OR THE HARLEY HARNESS WITHOUT FACTORY REAR SPEAKERS:

You will need to use the **4 inch** patch harness.
Set switch to **2 IN** and use input Channels 3 & 4.



The outputs use the standard color code as follows:

CH 1	Front Left	White ⊕	and	White / Black ⊖
CH 2	Front Right	Grey ⊕	and	Grey / Black ⊖
CH 3	Rear Left	Green ⊕	and	Green / Black ⊖
CH 4	Rear Right	Purple ⊕	and	Purple / Black ⊖

FOCAL
LISTEN BEYOND

VISIT US ONLINE:

WWW.FOCAL-AMERICA.COM