

IMPORTANT FDP SPORT V2 WIRING INFORMATION

FOR 2 CHANNEL INPUT USING THE **RCA HARNESS** (CH 1&2 INPUTS)
OR THE **HARLEY HARNESS** WITHOUT FACTORY REAR SPEAKERS:

You will need to use the **4 inch** patch harness.
Set switch to **2 IN** and use input Channels 3 & 4.



VISIT US ONLINE:
WWW.FOCAL-AMERICA.COM

The outputs use the standard color code as follows:

CH 1	Front Left	White ⊕	and	White / Black ⊖
				
CH 2	Front Right	Grey ⊕	and	Grey / Black ⊖
				
CH 3	Rear Left	Green ⊕	and	Green / Black ⊖
				
CH 4	Rear Right	Purple ⊕	and	Purple / Black ⊖
				